

Additional information



To tighten the nuts on car wheels you must follow a sequence of tightening, according to the number of nuts (Fig. 4.1).

The final torque values will be listed in the car handbook.




Fig. 4.4

